



№	Артикул	Наименование	К-во	№	Артикул	Наименование	К-во
1	8440-471510-0000010	Switch push rob group	1	9-1	8SJGD05-12B	Machine screw	1
1-1	8086-462701-0000110	Wheel Pin	1	9-2	8202-462203-0000000	Braking washer	1
1-2	8121-462701-0100110	Slide Wheel	1	9-3	8324-462701-0000000	Spring Leaf	1
1-3	8043-471503-0101710	Switch push rod	1	9-4	8043-462702-0001710	Divider Rod	1
2	8001-471502-0039410	Right rear left handle	1	9-5	8WF-05B	Washer	1
3	8SJAB50-16B	Self-trapping screw 5*16	4	9-6	8342-467601-0000000	Braking Rob spring	1
4	8005-471501-0000310	Strip	1	9-7	8186-462701-0000000	Clamp	1
5	8440-467607-0000010	Pump Group	1	9-8	8187-471502-0000000	Braking Rob Fix spring	1
5-1	8SJAB50-16B	Self-tapping screw 5*16	4	9-9	8147-471501-0000010	Braking	1
5-2	8187-471501-0000010	Pump fix board	1	9-10	8SJAB40-12B	Slef tapping screw 4*12	1
5-3	8123-472201-0000000	Worm gear	1	10	8042-462701-0100010	Control switch	1
5-4	8121-472201-0001710	Worm wheel	1	11	8CE-07B	E-circlip	1
5-5	8292-472203-0001710	Piston Support	1	12	8128-462201-0000000	Sprocket	1
5-6	8211-472202-0000000	Piston Sleeve	1	13	8208-462201-0000000	Gland Bonnet	1
5-7	234-1002	Oil tube	1	14	8342-462304-0000000	Spring	1
5-8	8336-472203-0000010	Pump body	1	15	8440-467610-0000013	Shaft Group	1
5-9	8SNAB30-12B	Self-trapping screw	2	15-1	8085-471501-0100000	Shaft	1
5-10	234-1002	Oil tube	1	15-2	8342-462301-0000000	Braking spring	1
5-11	8342-491201-0100000	Extension spring	1	15-3	8063-462701-0000000	Shaft sleeve	1
6	8SJAB40-25B	Self-trapping screw	2	15-4	8123-471502-0001710	Umbrella gear	1
7	8181-462701-0000000	Back plate	1	15-5	8BC-220807-ST03	608Z rear bearing	1
8	8440-467608-0000010	Oil Glid	1	15-6	8NH-08D	Self-trapping nut	1
8-1	8204-462201-0000120	O-Ring	2	16	8440-467611-0000010	Tank Group	1
8-2	8213-471501-0001710	Oil Adptor	1	16-1	8213-462701-0001710	Output adaptor	1
9	8440-471519-0000010	Braking Rod Group	1	16-2	8326-462701-0000010	Sponge	1



№	Артикул	Наименование	К-во	№	Артикул	Наименование	К-во
16-3	8348-462701-0001710	Adaptor Choke Plug	1	26-8	8SJGN04-10B	Machine screw	6
16-4	8331-462701-0000020	Rubber Sleeve	1	27	8SJAB40-16B	Self-tapping screw	1
16-5	8165-471501-0000010	Tank	1	28	8SJAB50-35B	Self-tapping screw	1
17	8SJAB50-35B	Self-tapping screw	2	29	8SJAB50-16B	Self-tapping screw	1
18	243-0079	Chain bar (16"oregon)	1	30	8181-471501-0000001	Buffer Board	1
19	243-0033	Saw chain (16"oregon)	1	31	8413-471501-0000010	Connection wire	1
20	8331-462101-0000110	Blade cover	1	32	8044-471501-0000110	Switch Trigger	1
21	8261-463101-0000000	Spanner	1	33	8440-463003-0000120	Oil cover Group	1
22	8207-463101-0000000	Tension nut	1	33-1	8335-463102-0000120	Value Group	1
23	8207-481001-0000000	Tension screw	1	33-2	8208-463101-0000120	Seal	1
24	8440-471501-0000110	End cap group	1	33-3	8020-463003-0000110	Tank cover	1
24-1	8208-462305-0000110	End cap seal	1	33-4	8185-463001-0000120	Sponge	1
24-2	8021-471501-0000110	End Cap	1	34	8SJAN50-20B	Self-tapping screw	4
24-3	8162-4775046-001	Brand label	1	35	8146-491901-0000110	Variable-speed Box	1
24-4	8334-463101-0000000	Shaft Sleeve	1	36	8SJAN50-55B	Self-tapping screw	2
24-5	8ND-08D	Flange nut	1	37	6NA-08D	Nut	1
25	8185-463101-0000110	Nut Shield	1	38	8123-471501-0000000	Small umbrella gear	1
26	8440-467613-0000013	Middle cover group	1	39	8WF-10B	Washer	1
26-1	8BC-221006-ST03	6900Z bearing	1	40	8440-491905-0000003	Rotor Groupware	1
26-2	8208-481501-0000120	output oil glib seal	1	40-1	8BC-261008-ST03	6201Z front bearing	1
26-3	8347-471801-0000000	Middle cover insert	1	40-2	8402-491903-0000010	Rotor	1
26-4	8206-462201-0200000	Machine screw	1	40-3	8BC-220707-ST03	698z rear bearing	1
26-5	8202-462205-0000120	seal shim	1	41	8440-471512-0039410	Housing Groupware	1
26-6	8023-471501-0000110	Middle cover	1	41-1	8182-471501-0001710	Wind screen	1
26-7	8SJAB50-30B	Self-tapping screw	1	41-2	8SJAN40-60B	Self-tapping screw	2



№	Артикул	Наименование	К-во	№	Артикул	Наименование	К-во
41-3	8405-481003-0000010	Stator	1				
41-4	8006-471503-0039410	Housing	1				
41-5	8409-467601-0000010	Brush holder	2				
42	8416-471401-0000010	Capacitor	1				
43	8440-467612-0000110	Assistance handle Group	1				
43-1	8003-471501-0000110	Left assistance handle	1				
43-2	8003-471502-0000110	Right assistance handle	1				
43-3	8SJAB40-14B	Self-tapping screw	7				
44	8440-471505-0039410	Rear left handle Group	1				
44-1	8422-471501-0000010	Cable	1				
44-2	8332-353201-0000120	Cable Sleeve	1				
44-3	8001-471501-0039410	Rear left handle	1				
44-4	8184-302201-0001710	Cable Holder	1				
44-5	8SJAB40-12B	Self-tapping screw	2				
45	8312-471501-0016610	Switch Knob	1				
46	8042-462201-0016610	Switch	1				
47	8407-463101-0000110	Brush cover	2				
48	8406-463103-0100000	Brush	2				
49	8342-471502-0000000	push rod spring	1				
50	8SJAB30-8B	Self-tapping screw	1				
51	8SJAB40-12B	Self-tapping screw	2				
52	8413-481004-0000020	Connecting wire	1				
53	8413-491501-0000020	Connecting wire	1				
54	8413-491908-0000010	Connecting wire	2				